


Artikel Nr. : 3808932/ 3810042/ 3810055



D- Montageanleitung

Partyzelt 3 x 3 m

F- Instructions D'utilisation

Tente loisirs 3 x 3 m

I- Manuale d'Istruzioni

Gazebo da ricevimento 3x3m

NL- Gebruiksaanwijzing

Partytent 3x3m

S- Instruktions Manual

3x3m Party Tält

CZ- Návod k použití







Párty stan 3x3m

SK- Návod na obsluhu

Stan na večierky 3 x 3 m

RO- Manual de instrucțiuni

Cort pentru petreceri 3 x 3 m

- (1)  x4
- (2)  x4
- (3)  x8
- (4)  x4
- (5)  x4
- (6)  x4

